



Sword Fish

Copyright by
MyWeb3000.com



Lower Left Fin to
curve to the Left.
Raise Left Fin to
curve to the Right.



Raise Right Fin to
curve to the Left.
Lower Right Fin to
curve to the Right.

— Cut Line
- - - Fold Line

Bend Rudders right to turn right.
Bend Rudders left to turn left.

Bend up Elevators if nose heavy.
Bend down Elevators if stalls.

Flying Tips: Launch the plane gently and keep the wings flat.