


# X-16 (Slim Mid-Fin)

Copyright by  
MyWeb3000.com




Lower Left Fin  
to roll to the Left.  
Raise Left Fin  
to roll to the Right.

Bend both fins  
down to  
raise nose.  
Bend up to  
drop nose.

Bend down Aileron  
if roll to the left.  
Bend up Aileron  
if roll to the right.

Bend up Elevators if nose heavy.  
Bend down Elevators if stall.



Raise Right Fin  
to roll to the Left.  
Lower Right-Fin  
to roll to the Right.

— Cut Line  
- - - Fold Line

Bend up Aileron  
if roll to the left.  
Bend down Aileron  
if roll to the right.

Bend Rudders right  
to turn right.  
Bend Rudders left  
to turn left.

Flying Tips: Launch the plane gently and keep the wings flat.